# GreaXPM



Particle-based continuum solutions for extreme geoengineering, geomechanics & geophysics applications



## **GeoXPM** Tutorial Manual

Ha H. Bui Tien V. Nguyen Giang D. Nguyen

#### Introduction

GeoXPM is a new generation of computational software package that was originally developed by Prof Ha H. Bui and his research team at Monash University in Australia based on the Smoothed Particle Hydrodynamics (SPH) method. It has been developed specifically to address the ever-evolving demands of solving intricate geotechnical engineering, geomechanics and geophysics challenges, particularly those involving fracturing, large deformation and flow behaviours of geomaterials. One standout feature of GeoXPM is its interactive graphical user-interface, which empowers users to effortlessly generate and modify complex computational models without encountering any obstacles. The calculation procedure within GeoXPM is both robust and fully automated, eliminating the need for extensive training or specialised knowledge. With GeoXPM, academics and professionals alike can unlock the full potential of engineering applications, pushing boundaries and delivering remarkable results that exceed expectations.

The tutorial explores a wide range of challenging and practical scenarios that encompass the intricate aspects of large deformation and post-failure behaviour in geomaterials. The main aim is to equip new users with a comprehensive understanding of GeoXPM. However, it is crucial to recognise that this tutorial should not be solely relied upon as the basis for practical projects. Instead, it serves as an invaluable resource to familiarise users with the functionalities and capabilities of the software.

Users are expected to possess a fundamental understanding of the SPH method and constitutive modelling of geomaterials. For those who are new to the software, it is highly recommended that they adhere to the default setting parameters and follow the step-by-step procedure meticulously to ensure accurate results. It is important to note that variations in hardware and software configurations may yield slight differences in the obtained results.

This Tutorial Manual does not provide the theoretical background information on the SPH method or elaborate on the specific details of the constitutive models utilised within the software. Therefore, users are highly advised to refer to the provided references for comprehensive information regarding the SPH method and constitutive models implemented in GeoXPM. These references offer in-depth insights into the underlying principles and methodologies employed, allowing users to gain a thorough understanding of the theoretical aspects involved.

### Example:

#### **2D Granular Flow**



In this project, we will model a simple granular flow. You will learn about using:

- Basic drawing with primitive objects
- Basic functions of GeoXPM, including Meshing, Staging, Material models and Visualisation

We will follow the below standard workflow:

- 1. Create a new project.
- 2. Create initial geometry.
- 3. Input SPH parameters.
- 4. Create material models.
- 5. Include objects in simulations and assign material properties.
- 6. Define construction stages.
- 7. Define meshing sequences.
- 8. Mesh objects generate particles for calculations.
- 9. Calculate.
- 10. Post-processing Visualisation: extract, data mining.

#### Step 1. Create a new project

- a. Click the "New Tool" button to create a new project as the given dialogue below.
- b. Enter the project name and project description.



New project Dialogue

#### Step 2. Create initial geometry

- a. Using the "Primitives" toolbox (Cube tool of soil (named "Soil column" object) and Boundaries (named "Bottom boundary", "Right boundary", and "Left boundary" objects).
- b. Define the dimensions and positions of each object.

|                              | 📑 🔚 🏊 📇 🐰 间 📋 😒                             | • 👌 • 🖉 •                    | C R Start                                   |
|------------------------------|---------------------------------------------|------------------------------|---------------------------------------------|
|                              | R R O - R + -> B -                          | Q. 8 10                      | 00000                                       |
|                              |                                             |                              | a 🖬 🗖 🖬 .                                   |
|                              |                                             |                              |                                             |
|                              | 🛃 r 🥅 r 🙋 🐴 🖆 😂 🏟                           | F 🔝 🔃 🗰 🕨                    | • 4 🖆 📶                                     |
| Combo View                   | x                                           | Combo View                   | ×                                           |
| Model Tasks                  | Stages                                      | Model Tasks                  | Stages                                      |
| Labels & Attribut            | es Description                              | Labels & Attribut            | es Description                              |
| Application                  |                                             | Application                  |                                             |
| 🗸 🔮 GeoXPM                   |                                             | 🗸 🔮 GeoXPM                   |                                             |
| 🧊 Simul                      | ation Domain (2D)                           | 🧊 Simul                      | ation Domain (2D)                           |
| 🧊 Soil ce                    | blumn                                       | 🧊 Soil ce                    | plumn                                       |
| 🧊 Left b                     | oundary                                     | 🧊 Left b                     | oundary                                     |
| 🧊 Right                      | boundary                                    | 🧊 Right                      | boundary                                    |
| 🧊 Botto                      | m boundary                                  | 🧊 Botto                      | m boundary                                  |
|                              |                                             |                              |                                             |
| Property                     | Value                                       | Property                     | Value                                       |
| Attachment                   |                                             | Attachment                   |                                             |
| Support                      |                                             | Support                      |                                             |
| Map Mode                     | Deactivated                                 | Map Mode                     | Deactivated                                 |
| Base                         |                                             | Base                         |                                             |
| ✓ Placement                  | [(0.00 0.00 1.00); 0.00 °; (0.00 mm 0.00 mm | ✓ Placement                  | [(0.00 0.00 1.00); 0.00 °; (0.00 mm 0.00 mm |
| Angle                        | 0.00 °                                      | Angle                        | 0.00 *                                      |
| > Axis                       | [0.00 0.00 1.00]                            | > Axis                       | [0.00 0.00 1.00]                            |
| <ul> <li>Position</li> </ul> | [0.00 mm 0.00 mm 0.00 mm]                   | <ul> <li>Position</li> </ul> | [0.00 mm 0.00 mm 0.00 mm]                   |
| x                            | 0.00 mm                                     | x                            | 0.00 mm                                     |
| У                            | 0.00 mm                                     | У                            | 0.00 mm                                     |
| Z                            | 0.00 mm                                     | Z                            | 0.00 mm                                     |
| Label                        | Soil column                                 | Label                        | Bottom boundary                             |
| Box                          | 200.00 mm                                   | Box                          |                                             |
| Length<br>Width              | 100.00 mm                                   | Length                       | 600.00 mm                                   |
|                              |                                             | Width                        | 100.00 mm                                   |
| Height                       | 100.00 mm                                   | Height                       | 10.00 mm                                    |
|                              |                                             |                              |                                             |
|                              |                                             |                              |                                             |
| View Data                    | GeoXPM                                      | View Data                    | GeoXPM                                      |
|                              |                                             |                              |                                             |



#### > Step 3. Input SPH parameters

a. Enter the SPH parameters into the dialogue.



| Execution parameters                   | ? ×                                                   |
|----------------------------------------|-------------------------------------------------------|
| Interaction kernel:                    | Cubic spline ~                                        |
| Approximation algorithm:               | Type 2: $\sigma_i/\rho_i^2 + \sigma_j/\rho_j^2  \lor$ |
| Particle distance (m):                 | 0.002                                                 |
| Critical timestep factor (CFL):        | 0.2                                                   |
| Time out data (iter):                  | 200.0                                                 |
| Adaptive simulation domain:            | $\square$                                             |
| Load initial stress:                   | Browse                                                |
| Artificial stress                      |                                                       |
| Enabled:                               | $\checkmark$                                          |
| Eps <sub>1</sub> coefficient:          | 0.5                                                   |
| Particle shifting                      |                                                       |
| Enabled:                               |                                                       |
| Detection algorithm:                   | Kernel gradient $\sim$                                |
| Free surface threshold(<=1):           | 0.8                                                   |
| Diffusion coefficient:                 | 2.0                                                   |
| Artificial viscosity                   |                                                       |
| Alpha coefficient:                     | 0.1                                                   |
| Beta coefficient:                      | 0                                                     |
| Etag coefficient:                      | 0.1                                                   |
| Autostop: (For plastic Stage)          |                                                       |
| Enabled:                               |                                                       |
| Normalized velocity(v/dp) lower bound: | 0.0001                                                |
|                                        |                                                       |
|                                        | OK Cancel                                             |

#### > Step 4. Input material properties

a. Click the Material property button, select the used constitutive model (i.e., Elasticperfectly plasticity (DP) model) provided in the "new material" button, and enter the material parameters.

| 📑 🖀 🖀 👗 🗐 🗊 😒     | • 🖄 • 🐯 • 😂 隆 🔿 Start |
|-------------------|-----------------------|
| 🖲 🔍 🔕 · 🗭 🔶 🔊 ·   | Q.\$ 3333 386         |
| 1 🗍 🥥 🛦 🔾 🗂 🏭 💕   | 30AC7604              |
| 🖡 • 🖪 • 💼 🕾 🖆 餐 🌣 | 🖸 🕄 🖗 💽 🥠 🖆 📶         |

| 🐕 Materials configuration |                            |                | ? | × |
|---------------------------|----------------------------|----------------|---|---|
| Materials                 | Material Properties        |                |   |   |
| New Material              | Model:                     | Drucker-Prager |   |   |
| Soil column material      | Young Modulus (N/m2):      | 840000.0       |   |   |
|                           | Poisson Ratio:             | 0.3            |   |   |
|                           | Friction Angle:            | 19.8           |   |   |
|                           | Dilatancy Angle:           | 0.0            |   |   |
|                           | Strength reduction factor: | 1.0            |   |   |
|                           | Cohesion (N/m2):           | 0.0            |   |   |
|                           | Unit Weight (kg/m3):       | 2650.0         |   |   |
|                           | Unit Weight (kg/m3):       | 2650.0         |   |   |

**Hint:** The timestep for the elastoplastic model depends heavily on the sound speed, which depends on the material's Young Modulus and Unit Weight. Decreasing Young Modulus and increasing Unit Weight will increase the timestep, making the simulation faster but risking extreme particle overlapping and penetration.

### Step 5. Include objects in simulations and assign material properties

a. Soil object: Select the "Soil column" in the "Model" tab and click "Add to Simulation" under the "GeoXPM" tab. And then, select the "Type of object" as "Soil" and the meshing mode as "Solid". In the next step, click the "Assign" button to assign the "Soil column material" to the soil in the dialogue of the material configuration.

| Model Tasks Stages              | Model Tasks        | Stages           |             |        |                                               |                |
|---------------------------------|--------------------|------------------|-------------|--------|-----------------------------------------------|----------------|
| Labels & Attributes Description | Labels & Attribute | s                | Description |        |                                               |                |
| Application                     | Application        |                  |             |        |                                               |                |
| ✓ Ø GeoXPM                      | 🗸 🔮 GeoXPM         |                  |             |        |                                               |                |
| Simulation Domain (2D)          |                    | tion Domain (2D) |             |        |                                               |                |
| 🚅 Soil column 1                 | 🗊 Soil co          |                  |             |        |                                               |                |
| 🚅 Left boundary                 | 🗊 Left bo          |                  |             |        |                                               |                |
| 🗊 Right boundary                | 🗊 Right b          |                  |             |        |                                               |                |
| 🚅 Bottom boundary               | 🗊 Botton           | n boundary       |             |        |                                               |                |
|                                 |                    |                  |             |        |                                               |                |
|                                 |                    |                  |             |        |                                               |                |
|                                 |                    |                  |             |        |                                               |                |
|                                 |                    |                  |             |        |                                               |                |
|                                 |                    |                  |             |        |                                               |                |
|                                 |                    |                  |             |        |                                               |                |
|                                 | Property           | Value            |             |        | Material configuration                        | ? ×            |
|                                 | Type of object     | Soil             | 4           | ~      | Re Material configuration                     |                |
|                                 |                    |                  | 4           |        | Select a material: Soil column material 🗸     | 7 Object Id: 0 |
|                                 | Meshing mode       | Solid            | 5           | ~      | Model: Drucker-Prager                         |                |
|                                 | Faces configuratio | n                | Configure   |        | Unit weight: 2650.0                           |                |
|                                 | Material           |                  | Assign      | 6      | Young Modulus: 840000.0<br>Poisson Ratio: 0.3 |                |
|                                 | Boundary type      | No-slip          |             | $\sim$ | Friction Angle: 19.8<br>Dilatancy Angle: 0.0  |                |
| Add to Simulation 3             | Autofill           | Enabled          |             |        | Cohesion: 0.0                                 |                |
|                                 | Object ID          | 0                |             | -      | Strength reduction factor: 1.0                |                |
|                                 |                    |                  |             |        |                                               |                |
|                                 |                    |                  |             |        |                                               |                |
|                                 |                    |                  |             |        |                                               |                |
|                                 |                    |                  |             |        |                                               |                |
|                                 |                    |                  |             |        |                                               |                |
|                                 |                    | Remove from S    | imulation   |        |                                               |                |
| View Data GeoXPM 2              | View Data          | GeoXPM           |             |        |                                               | Cancel OK      |

b. "Bottom boundary" object: Select the "Bottom boundary" in the "Model" tab and click "add to Simulation" under the "GeoXPM" tab. And then select the "Type of object" as "Boundary", meshing mode as "Face", and the "Boundary type" as "No-slip". In the next step, click the "Configure" button to define the boundary surface in the dialogue of the face configuration.

| Model Tasks Stages                                                                                                                                      | Model Tasks                     | Stages                                     |        |                      |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|--------------------------------------------|--------|----------------------|
| Labels & Attributes Description<br>Application<br>GeoXPM<br>Simulation Domain<br>Soil column<br>Left Boundary<br>Right Boundary<br>Bottom boundary<br>1 | ■ Soil co<br>Left Bo<br>Right E | tion Domain<br>Iumn<br>uundary<br>Boundary | n      |                      |
|                                                                                                                                                         | Property                        | h boundary<br>Value                        |        | _                    |
|                                                                                                                                                         | Type of object                  | Boundary                                   | 4 、    | -                    |
|                                                                                                                                                         | Meshing mode                    | Face                                       | 5      | -                    |
|                                                                                                                                                         | Faces configuratio              |                                            | figure |                      |
|                                                                                                                                                         | Material                        |                                            | sign   |                      |
|                                                                                                                                                         | Boundary type                   | No-slip                                    | 6      |                      |
|                                                                                                                                                         | Autofill                        | Enabled                                    |        |                      |
|                                                                                                                                                         | Object ID                       | 2                                          | 3      |                      |
|                                                                                                                                                         |                                 |                                            |        |                      |
| Add to Simulation 3                                                                                                                                     |                                 |                                            |        | 🌄 Faces config ? 🛛 🗙 |
|                                                                                                                                                         |                                 |                                            |        | All faces            |
|                                                                                                                                                         |                                 |                                            |        | Front face Back face |
|                                                                                                                                                         |                                 |                                            |        | Top face Sottom face |
|                                                                                                                                                         |                                 |                                            |        | Left face Right face |
|                                                                                                                                                         |                                 |                                            |        | Layers: 7            |
|                                                                                                                                                         |                                 |                                            |        |                      |
|                                                                                                                                                         |                                 | Remove from Simulati                       | on     | 0,-1,-2              |
| View Data GeoXPM 2                                                                                                                                      | View Data                       | GeoXPM                                     |        | OK Cancel            |

c. "Left boundary" object. Select the "Left boundary" in the "Model" tab and click "Add to Simulation" under the "GeoXPM" tab. And then select the "Type of object" as "Boundary", meshing mode as "Face", and the "Boundary type" as "Free-slip". In the next step, click the "Configure" button to define the boundary surface in the dialogue of the face configuration.

| Model Tasks Stages                                                                                                                                     | Model Tasks                                                                                             | Stages                    |                               |
|--------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|---------------------------|-------------------------------|
| Labels & Attributes Description<br>Application<br>V Ø GeoXPM<br>Simulation Domain<br>Soil column<br>Ceft Boundary<br>Right Boundary<br>Sottom boundary | Labels & Attributes<br>Application<br>GeoXPM<br>Simulati<br>Soil colu<br>Left Bou<br>Right Bo<br>Bottom | on Domain<br>Imn<br>ndary |                               |
|                                                                                                                                                        | Property                                                                                                | Value                     |                               |
|                                                                                                                                                        | Type of object                                                                                          | Boundary <b>4</b> ~       |                               |
|                                                                                                                                                        | Meshing mode                                                                                            | Face 5 ~                  |                               |
|                                                                                                                                                        | Faces configuration                                                                                     | Configure                 |                               |
|                                                                                                                                                        | Material                                                                                                | Assign                    |                               |
|                                                                                                                                                        | Boundary type                                                                                           | Free-slip 6 ~             |                               |
|                                                                                                                                                        | Autofill                                                                                                | Enabled                   |                               |
|                                                                                                                                                        | Object ID                                                                                               | 0                         |                               |
|                                                                                                                                                        |                                                                                                         |                           |                               |
| Add to Simulation 3                                                                                                                                    |                                                                                                         |                           | 陀 Free-slip face configurat 🛛 |
|                                                                                                                                                        |                                                                                                         |                           | ○ Front face ○ Back face      |
|                                                                                                                                                        |                                                                                                         |                           | ○ Top face ○ Bottom face      |
|                                                                                                                                                        |                                                                                                         |                           | Left face     Right face      |
|                                                                                                                                                        |                                                                                                         |                           | Layers: 7                     |
|                                                                                                                                                        |                                                                                                         |                           | 0,-1,-2                       |
|                                                                                                                                                        |                                                                                                         | Remove from Simulation    | ОК                            |
| View Data GeoXPM 2                                                                                                                                     | View Data G                                                                                             | GeoXPM                    |                               |

d. Repeat step c for the "Right boundary" object.

| Model Tasks Stages  |             | Model T                                | Tasks      | Stages     |               |      |    |              |             |
|---------------------|-------------|----------------------------------------|------------|------------|---------------|------|----|--------------|-------------|
| pplication  GeoXPM  | Description | Labels & Att<br>Application<br>V 🖉 Geo | хрм        |            | Description   |      |    |              |             |
| 📫 Simulation Domain |             | - 🗳 S                                  | Simulatio  | n Domain   |               |      |    |              |             |
| 🗊 Soil column       |             | I I I I I I I I I I I I I I I I I I I  | Soil colur | mn         |               |      |    |              |             |
| 🗊 Left Boundary     |             | 📫 📫 📫                                  | Left Boun  | ndary      |               |      |    |              |             |
| 🗊 Right Boundary    |             | 🚅 I                                    | Right Bou  | undary     |               |      |    |              |             |
| 💕 Bottom boundary   |             | 🚅 E                                    | Bottom b   | oundary    |               |      |    |              |             |
|                     |             | Property                               |            | Value      |               |      |    |              |             |
|                     |             | Type of obje                           | ect        | Boundary   |               | 4    | ~  |              |             |
|                     |             | Meshing mo                             | ode        | Face       |               | 5    | ~  |              |             |
|                     |             | Faces config                           | guration   |            | Confi         | qure |    |              |             |
|                     |             | Material                               |            |            | Assi          |      |    |              |             |
|                     |             | Boundary ty                            | /pe        | Free-slip  |               | 6    | ~  |              |             |
|                     |             | Autofill                               | j l        | Enabled    | ł             |      |    |              |             |
|                     |             | Object ID                              |            | 1          |               |      | \$ |              |             |
|                     |             |                                        |            |            |               |      |    |              |             |
| Add to Si           | mulation 3  |                                        |            |            |               |      |    |              |             |
|                     | - J         |                                        |            |            |               |      |    | Faces config | J ? ×       |
|                     |             |                                        |            |            |               |      |    | All faces    |             |
|                     |             |                                        |            |            |               |      |    | Front face   | Back face   |
|                     |             |                                        |            |            |               |      |    | Top face     | Bottom face |
|                     |             |                                        |            |            |               |      |    |              |             |
|                     |             |                                        |            |            |               |      |    | Left face    | Right face  |
|                     |             |                                        |            |            |               |      |    | Layers: 7    |             |
|                     |             |                                        |            |            |               |      |    | 0,-1,-2      |             |
|                     |             |                                        |            | Remove fro | om Simulatior | n    |    |              | Course 1    |
| View Data GeoXPM    | 2           | View Da                                | ata Ge     | eoXPM      |               |      |    | ОК           | Cancel      |

#### > Step 6. Define construction stages

- a. Go to the Stage tab and click "Add stage".
- b. Click the checkbox "Activated objects" to activate all objects in the simulation.

- c. Set Stage 0 for the stress initialisation using the elastic loading method. Set the "Type of calculation" to "Elastic", "Stress initialisation method" to "Elastic loading" and the "Time of simulation" to 8000.
- d. Tick the checkbox next to "Reset displacement to 0" to reset displacement after stress initialisation.
- e. Add Stage 1 for the elastoplastic analysis. Click the checkbox "Activated objects" to activate all objects in the simulation, then untick "Right boundary" to deactivate (remove) the right wall in this stage.
- f. Set Stage 1's "Type of calculation" to "Plastic" and the "Time of simulation" to 30000.



#### > Step 7. Define the meshing sequence

Click the meshing order button, and change the meshing sequence for the included objects in step 5. Note that the lower object will overwrite the upper one if there are overlaps.



#### > Step 8. Generate particles for computations

- a. Before meshing, click the "Save" button (<sup>1</sup>). In the "3D/2D Switching" dialogue, tick "Save case as 2D" checkbox, then input 50 to cut a section along the Y=50mm axis. Click "Apply" to see the changes and then "Save" to save the project.
- b. Click the "Autofit simulation domain" button ()) to fit all simulated objects in the Simulation domain.
- a. Click the "Generate particles" button( b) to mesh the computational domain.
- b. After meshing, click "Open with Paraview" to view the particle configuration.

|                              |       | - 2   | ) 📇 🔏 🗐 🗊 🌖 • 🖄   | - 🖏 - 😂 🎼 🔿 Start             |              |
|------------------------------|-------|-------|-------------------|-------------------------------|--------------|
|                              |       | 9.0   | · 👧 ← ⇒ 🔊 · Q · ( | \$ 🗊 🕼 🕼 🕼 🕼 🕼                |              |
|                              |       |       | 🔺 👄 🧻 🚋 🎜 🌢 🄇     |                               |              |
|                              |       | - 🖪 - | 💩 🔁 🖆 😂 🛊 🔝 🕯     | l 🙀 💽 🦩 🦩                     |              |
|                              |       |       |                   |                               |              |
| 3D/2D Switching              |       | ×     |                   | 🔯 Generate particles          | ? ×          |
| Save case as 2D:             |       |       |                   |                               |              |
| Cutting section Y (mm): 50.0 |       |       |                   | 5750 particles was generated. |              |
| Apply Save                   | Ca    | ancel |                   | Open with Paraview            | ОК           |
| Save the proje               | ct as | s 2D  | _                 | Check the particle co         | onfiguration |

#### > Step 9. Start the Calculation

Click the "Run" button and start the calculations.

| ] 🔚 🏝 📇   🔏 🦷 🗊   🌜 + 🕭 + 🗒 - 🖓 |   | Start |
|---------------------------------|---|-------|
| s 🔍 🛇 • 👧 🗲 🔶 🔊 • 🔍 🕄 🖾         |   | 🗇 🗐 ( |
| 🔓 - 📑 - 📷 🔁 🖆 😂 🌼 🔝 ᡝ 🁹 💽       | 4 | 😭 III |

| S GeoXPM Simulation: 9.47%                                                                                                               |              | ?          | ×   |
|------------------------------------------------------------------------------------------------------------------------------------------|--------------|------------|-----|
| Simulation Data<br>Case name: GranularFlow2D<br>Total number of particles: 5750<br>Estimated time to complete simulation: 0:01:09.354214 |              |            |     |
|                                                                                                                                          | Details Canc | el Simulat | ion |

#### > Step 10. Visualisation

- a. Click on the tool "Export output data to VTU format" to start exporting data to Paraview anytime during the simulation or after completion.
- b. When the export is done, Paraview will open with already imported results. All the data can be customised and visualised from here.



#### **References:**

- Bui H.H, Nguyen V.T & Nguyen G.D (2023). GeoXPM: Particle-based continuum solutions for extreme geoengineering, geomechanics & geophysics applications, Tutorial Manual. <u>Link</u>
- 2. Bui H.H, Nguyen G.D (2021). Smoothed particle hydrodynamics (SPH) and its applications in geomechanics: From solid fracture to granular behaviour and multiphase flows in porous media, *Computers and Geotechnics* 138, 104315. Link
- Bui H.H, Fukagawa R, Sako K & Ohno S (2008). Lagrangian mesh-free particles method (SPH) for large deformation and failure flows of geomaterial using elasticplastic soil constitutive model, International Journal for Numerical and Analytical Methods in Geomechanics, Vol.32(12), pp.1537-1570. <u>Link</u>